

## Billboard Sign Top Box Pieces (All cut from 1/4" Baltic Plywood)

Top Panel 6" x 2" (1/4" Baltic Plywood)

Back Panel 6" x 3 1/2" (1/4" Baltic Plywood)

Front Panel 6" x 4" (1/4" Baltic Plywood)

This front section is a cutout frame with approx. 1/4" around the edges. Can be larger if you wish. This can be cut out on a scroll saw.

Compared to the Back Panel there is a 1/2" overhang at the bottom which will overlap the wood base for attachment (See Photos)

1/8" holes should be drilled in each lower corner for attachment to the billboard Base.

### Side Panels

●  
Cut 2 - One for each side.

●  
Drill 1/4" holes for venting

●  
1 1/4" x 3 1/2"  
(1/4" Baltic Plywood)


## Parts for Billboard Base

●	Base of Billboard -- Stand For The Top Case	●
6 3/4" x 2 1/2" (1" Pine or Other Wood)		
Cut the saw kerf lines by running over saw blade about 1/8" to 1/4" deep into the wood (or leave plain if you prefer. Round-over left and right edges if you prefer.		

Bottom Platform for the Base  
7 1/4" x 1 3/4" (1/4" Baltic Plywood)  
Glue this to the bottom of the base on center to keep the billboard from falling over.

All sizes are approximate, you can adjust them to change the size of the overall billboard. If you don't want to measure each piece just attach these patterns to the wood and cut around them.

All pieces are glued and clamped together to make the billboard box (top section). The billboard box is then fastened to the base using two small 1/8" wood screws.



Top Panel 6" x 2"  
(1/4" Baltic Ply)

Side Panel A 1 1/4" x 3 1/2"  
(1/4" Baltic Ply)

Back Panel 6" x 3 1/2"  
(1/4" Baltic Ply)

Side Panel B 1 1/4" x 3 1/2"  
(1/4" Baltic Ply)

Billboard Base  
6 3/4" x 2 1/2"  
(3/4" - 1" Pine)

Front Panel 6" x 4"  
Cut Out Center Section  
(1/4" Baltic Ply)

Bottom Platform  
7 1/4" x 1 3/4"  
1/4" Baltic Ply)